

At last-

A really comfortable glass cutter !

To use your new Comfort Grip Glass Cutter-

- Unscrew the brass plug at the base of the barrel.
- Use an applicator to squirt your favorite cutting fluid into the internal reservoir. Replace the brass plug. In order to begin the flow of cutting fluid the first time, you may need to prime the wick. To prime the wick, remove the cutting head by loosening the set screw and gently pulling the head off the stem. Immerse the entire stem in cutting fluid for about 15 minutes. Replace the head and tighten the set screw over the flat notch in the stem so that the head may move slightly up and down on the stem.
- Draw your pattern onto the glass with a contrasting permanent marker.
- Place the cutting wheel at your starting point, apply firm pressure against the glass, and draw the wheel down the pressure applied remain constant throughout the score. For long, straight cuts hold the base of the cutter closer to the glass. For intricate cuts hold the cutter more upright. Do not run the cutting wheel over the edge of the glass.
- You should see a faint line in the glass made by the cutting wheel. If there is evidence of chipping along the line, too much pressure was used.
- Tap the glass directly under the line with the brass ball on the base of the grip of the cutter. You should see the score line become more distinct.
- To break the glass, begin by placing your thumbs on the top of the glass on each side of the score line. Place the sides of each forefinger under your thumbs on the opposite side of the glass. With a smooth upward motion, snap the glass.



***Gryphon Corporation • 12417 Foothill Blvd. • Sylmar • CA • 91342 • www.gryphoncorp.com
Made in China—Patents Pending***